



Note: Leave base to set for 96 hours before attaching post  
Remove coverplate before bolting post to base.