**Parts List** \*\* Please note that although graphical representation may ITEM PART NUMBER QTY differ from actual springer supplied, this fixing pack documentation is common to all Fahr Sit-in Springers. 1 SIT-IN SPRINGER TOP SUB ASSY' 2 4 M10x40 COUNTERSINK SS 3 4 DONUT FLOWER BASE Fig 1: Sit-in Springer Assembly 4 4 M10 WASHER SS 5 5 M10 NYLOC NUT SS 6 4 DONUT FLOWER CAP 7 400mm SPRING MIDDLE ASSY' В 8 Ground Anchor Set EGA500 **Product Features** Type Information 2-5 years Age Range Free Fall Height Less than 0.6m Top Assy' =20Kg Maximum Mass Spring Assy' = 14Kg **Tooling Required** M10 Spanners & Allen Key Spare Parts Yes - Off the shelf items Available? Year of 2013 Manufacture D **TUV** Certified Yes Fig 2: Maximum Unit Size Fig 3: Safety Zone (Not to Scale) 795 3795 Ε 1500 3775 Ground Level **Product Inspection** Fig 4: Full Overview This product should be inspected by a competent person who is familiar with BS EN 1176 to the following inspection schedule: G Minimum Inspection Schedule Inspection Type Inspection Frequency **Every Month** Ground Anchor: Visual Every 6 Months Supplied as loose components Functionality Every 12 Months with Fixing Pack / instructions Comprehensive Sit-in Springer Installation Guide FI-SIS-GI-2013-A Fahr Industries Ltd, Spitfire Road, Old Sarum, Salisbury, Wilts, SP4 6GB Н Tel: 01722 349793 Fax: 01722 349792 Email: info@fahr-industries.com Web: www.fahr-industries.com No part of this document may be copied or used without the express written permission of FAHR INDUSTRIES LTD (c) FAHR 2012